

10,000 KM OR 6 MONTH SERVICE (whichever occurs first)

MAINTENANCE FOR NORMAL OPERATING CONDITIONS

IMPORTANT: Check the Toyota on-line system for any outstanding manufacturer service campaigns.


- Replace engine oil and filter
- Lubricate propeller shaft (4X4 models)
- Tighten propeller shaft bolts (4X4 models)

Inspect the following:

- Drive belts
- Battery
- Water sediment accumulator (diesel models)
- Engine air cleaner filter (diesel models)
- Brake pads and discs
- Brake fluid
- Clutch fluid
- Power steering fluid
- Drive shaft boots (4X4 models)
- Tyres and inflation pressures
- Lights, horns, wipers and washers
- Road test vehicle

10,000 km or 6 month (whichever occurs first)

Maintenance Record



TOYOTA GENUINE
PARTS, SERVICE & ACCESSORIES

This service has been completed by an
Authorised Toyota Service Centre using
Toyota Genuine Parts:

Date: 18.7.08

Km: 11,200

Toyota Service Centre Verification

00	110	120	130	140	150	160	170	180	190	200
60	66	72	78	84	90	96	102	108	114	120
0.7	0.6	1.4	0.6	0.7	0.6	1.7	0.6	0.7	0.6	1.4
0.8	0.6	1.5	0.6	0.7	0.6	1.8	0.6	0.7	0.6	1.7
0.8	0.6	1.5	0.6	0.7	0.6	1.8	0.6	0.7	0.6	1.6
0.9	0.7	2.2	0.7	0.8	1.1	2.4	0.7	0.8	0.7	2.3
1.0	0.7	1.9	0.7	0.9	0.7	2.2	0.7	0.9	0.7	2.0
1.0	0.7	1.9	0.7	0.9	0.7	2.2	0.7	0.9	0.7	2.0
1.0	0.7	2.4	0.7	0.9	1.8	2.6	0.7	0.9	0.7	2.5
1.0	0.7	2.4	0.7	0.9	1.8	2.6	0.7	0.9	0.7	2.5

Items may be required to correct items or replace at the appropriate services, however additional

20,000 KM OR 12 MONTH SERVICE *(whichever occurs first)*

20,000 km or 12 month *(whichever occurs first)* Maintenance Record

MAINTENANCE FOR NORMAL OPERATING CONDITIONS

IMPORTANT: Check the Toyota on-line system for any outstanding manufacturer service campaigns.

- Replace engine oil and filter
- Lubricate propeller shaft (4X4 models)
- Tighten propeller shaft bolts (4X4 models)

Inspect the following:

- Drive belts
- Exhaust pipes/mountings
- Battery
- Water sediment accumulator (diesel models)
- Engine air cleaner filter (all models)
- Brake pedal and parking brake
- Brake pads and discs
- Brake fluid
- Clutch fluid
- Brake pipes and hoses
- Power steering fluid
- Steering wheel and linkage
- Drive shaft boots (4X4 models)
- Suspension ball joints and dust covers
- Front (4X4 models) and rear differential oil
- Front and rear suspensions (4X4 models)
- Tyres and inflation pressures
- Lights, horns, wipers and washers
- Air conditioner, including refrigerant level
- Road test vehicle



This service has been completed by an
Authorised Toyota Service Centre using
Toyota Genuine Parts:

Date: 8.5.09
Km:


Toyota Service Centre Verification

Towong Swine

30,000 KM OR 18 MONTH SERVICE (whichever occurs first)

30,000 km or 18 month
(whichever occurs first)

Maintenance Record

 TOYOTA GENUINE <small>PARTS, SERVICE & ACCESSORIES</small>
<p>This service has been completed by an Authorised Toyota Service Centre using Toyota Genuine Parts:</p> <p>Date: 11.8.09 Km: 30600</p> <p>Toyota Service Centre Verification <i>Tewang</i> <i>Shua</i></p>

MAINTENANCE FOR NORMAL OPERATING CONDITIONS

IMPORTANT: Check the Toyota on-line system for any outstanding manufacturer service campaigns.

- Replace engine oil and filter
- Replace engine air cleaner filter (diesel models)
- Lubricate propeller shaft (4X4 models)
- Tighten propeller shaft bolts (4X4 models)

Inspect the following:

- Drive belts
- Battery
- Water sediment accumulator (diesel models)
- Brake pads and discs
- Brake fluid
- Clutch fluid
- Power steering fluid
- Drive shaft boots (4X4 models)
- Tyres and inflation pressures
- Lights, horns, wipers and washers
- Road test vehicle

40,000 km or 24 month

(whichever occurs first)

Maintenance Record

35900
Jan 11-09



This service has been completed by an
Authorised Toyota Service Centre using
Toyota Genuine Parts:

Date: 5-2-10

Km: 39800

Toyota Service Centre Verification

Tawong Shue

40,000 KM OR 24 MONTH SERVICE (whichever occurs first)

MAINTENANCE FOR NORMAL OPERATING CONDITIONS


IMPORTANT: Check the Toyota on-line system for any outstanding manufacturer service campaigns.

- Replace engine oil and filter
- Replace spark plugs (petrol models)
- Replace engine air cleaner filter (petrol models)
- Lubricate propeller shaft (4X4 models)
- Tighten propeller shaft bolts (4X4 models)
- Replace brake fluid
- Replace front (4X4) and rear differential oil
- Inspect the following:**
 - Check valve clearances (diesel models)
 - Drive belts
 - Cooling and heater system; check that the radiator and condenser are not blocked with leaves, dirt, or insects, and the hose connections for installation condition and corrosion
 - Engine coolant
 - Exhaust pipes/mountings
 - Battery
 - Water sediment accumulator (diesel models)
 - Engine air cleaner filter (diesel models)
 - Diesel smoke (diesel models)
- Fuel tank cap, fuel lines and connections (diesel models)
- Fuel tank cap, fuel lines, connections and vapour control valve (petrol models)
- Charcoal canister (petrol models)
- Brake pedal and parking brake
- Brake linings/drums, including parking brake
- Brake pads and discs
- Clutch fluid
- Brake pipes and hoses
- Power steering fluid
- Steering wheel and linkage
- Drive shaft boots (4X4 models)
- Suspension ball joints and dust covers
- Automatic transmission fluid
- Manual transmission oil
- Transfer oil (4X4 models)
- Front and rear suspensions (all models)
- Tyres and inflation pressures
- Lights, horns, wipers and washers
- Air conditioner, including refrigerant level
- Road test vehicle

50,000 KM OR 30 MONTH SERVICE (whichever occurs first)

50,000 km or 30 month (whichever occurs first)

Maintenance Record

 TOYOTA GENUINE <small>PARTS, SERVICE & ACCESSORIES</small>
This service has been completed by an Authorised Toyota Service Centre using Toyota Genuine Parts:
Date: <u>17-8-10</u> Km: <u>50000</u>
Toyota Service Centre Verification <i>Towong Shire</i>

MAINTENANCE FOR NORMAL OPERATING CONDITIONS

IMPORTANT: Check the Toyota on-line system for any outstanding manufacturer service campaigns.

- Replace engine oil and filter
- Lubricate propeller shaft (4X4 models)
- Tighten propeller shaft bolts (4X4 models)

Inspect the following:


- Drive belts
- Battery
- Water sediment accumulator (diesel models)
- Engine air cleaner filter (diesel models)
- Brake pads and discs
- Brake fluid
- Clutch fluid
- Power steering fluid
- Drive shaft boots (4X4 models)
- Tyres and inflation pressures
- Lights, horns, wipers and washers
- Road test vehicle

*Oil + Filter
65300*



60,000 KM OR 36 MONTH SERVICE *(whichever occurs first)*

60,000 km or 36 month *(whichever occurs first)* Maintenance Record

 <p>TOYOTA GENUINE PARTS, SERVICE & ACCESSORIES</p>
<p>This service has been completed by an Authorised Toyota Service Centre using Toyota Genuine Parts:</p> <p>Date: <i>8.2.2007</i> Km: <i>60,200</i></p>
<p>Toyota Service Centre Verification</p>

MAINTENANCE FOR NORMAL OPERATING CONDITIONS

IMPORTANT: Check the Toyota online system for any outstanding manufacturer service campaigns.

- Replace engine oil and filter
- Clean air flow meter
- Replace engine air cleaner filter (diesel models)
- Lubricate propeller shaft (4X4 models)
- Tighten propeller shaft bolts (4X4 models)

Inspect the following:

- Drive belts
- Exhaust pipes/mountings
- Battery
- Water sediment accumulator (diesel models)
- Engine air cleaner filter (petrol models)
- Brake pedal and parking brake
- Brake pads and discs
- Brake fluid
- Clutch fluid
- Brake pipes and hoses
- Power steering fluid
- Steering wheel and linkage
- Drive shaft boots (4X4 models)
- Suspension ball joints and dust covers
- Front (4X4 models) and rear differential oil
- Front and rear suspensions (4X4 models)
- Tyres and inflation pressures
- Lights, horns, wipers and washers
- Air conditioner, including refrigerant level
- Road test vehicle

Oil at 55,000 65,000

70,000 km or 42 month
(whichever occurs first)
Maintenance Record



This service has been completed by an
Authorised Toyota Service Centre using
Toyota Genuine Parts:

Date: *24.6.2011*
Km: *70300*

Toyota Service Centre Verification

70,000 KM OR 42 MONTH SERVICE
(whichever occurs first)

MAINTENANCE FOR NORMAL OPERATING CONDITIONS

IMPORTANT: Check the Toyota on-line system for any outstanding manufacturer service campaigns.

Fuel Filter Changed

- Replace engine oil and filter
- Lubricate propeller shaft (4X4 models)
- Tighten propeller shaft bolts (4X4 models)

Inspect the following:

- Drive belts
- Battery
- Water sediment accumulator (diesel models)
- Engine air cleaner filter (diesel models)
- Brake pads and discs
- Brake fluid
- Clutch fluid
- Power steering fluid
- Drive shaft boots (4X4 models)
- Tyres and inflation pressures
- Lights, horns, wipers and washers
- Road test vehicle

80,000 km or 48 month
(whichever occurs first)
Maintenance Record



This service has been completed by an
Authorised Toyota Service Centre using
Toyota Genuine Parts:

Date: 20.12.2014
Km: 79400

Toyota Service Centre Verification

80,000 KM OR 48 MONTH SERVICE
(whichever occurs first)

MAINTENANCE FOR NORMAL OPERATING CONDITIONS

IMPORTANT: Check the Toyota on-line system for any outstanding manufacturer service campaigns.

- Replace engine oil and filter
- Replace spark plugs (petrol models)
- Replace engine air cleaner filter (petrol models)
- Replace fuel filter (petrol models)
- Lubricate propeller shaft (4X4 models)
- Tighten propeller shaft bolts (4X4 models)
- Replace brake fluid
- Replace front (4X4) and rear differential oil

Inspect the following:

- Check valve clearances (IKD-FTV & IGR-FE engines)
- Drive belts
- Cooling and heater system; check that the radiator and condenser are not blocked with leaves, dirt, or insects, and the hose connections for installation condition and corrosion
- Engine coolant
- Exhaust pipes/mountings
- Battery
- Water sediment accumulator (diesel models)
- Engine air cleaner filter (diesel models)

- Diesel smoke (diesel models)
- Fuel tank cap, fuel lines and connections (diesel models)
- Fuel tank cap, fuel lines, connections and vapour control valve (petrol models)
- Charcoal canister (petrol models)
- Brake pedal, parking brake
- Brake linings/drums, including parking brake
- Brake pads and discs
- Clutch fluid
- Brake pipes and hoses
- Power steering fluid
- Steering wheel and linkage
- Drive shaft boots (4X4 models)
- Suspension ball joints and dust covers
- Automatic transmission fluid
- Manual transmission oil
- Transfer oil (4X4 models)
- Front and rear suspensions (all models)
- Tyres and inflation pressures
- Lights, horns, wipers and washers
- Air conditioner, including refrigerant level
- Road test vehicle

90,000 KM OR 54 MONTH SERVICE
(whichever occurs first)

MAINTENANCE FOR NORMAL OPERATING CONDITIONS

IMPORTANT: Check the Toyota on-line system for any outstanding manufacturer service campaigns.

- Replace engine oil and filter
- Replace engine air cleaner filter (diesel models)
- Lubricate propeller shaft (4X4 models)
- Tighten propeller shaft bolts (4X4 models)

Inspect the following:

- Drive belts
- Battery
- Water sediment accumulator (diesel models)
- Brake pads and discs
- Brake fluid
- Clutch fluid
- Power steering fluid
- Drive shaft boots (4X4 models)
- Tyres and inflation pressures
- Lights, horns, wipers and washers
- Road test vehicle

90,000 km or 54 month
(whichever occurs first)
Maintenance Record



This service has been completed by an Authorised Toyota Service Centre using Toyota Genuine Parts:


Date: 7-2-2013
Km: 90,100

Toyota Service Centre Verification

oil change
85000
25-7-12

100,000 KM OR 60 MONTH SERVICE *(whichever occurs first)*

100,000 km or 60 month *(whichever occurs first)* Maintenance Record



TOYOTA GENUINE
PARTS, SERVICE & ACCESSORIES

This service has been completed by an
Authorised Toyota Service Centre using
Toyota Genuine Parts:

Date:

Km: 100,200

Toyota Service Centre Verification
Bowag
Shide

MAINTENANCE FOR NORMAL OPERATING CONDITIONS

IMPORTANT: Check the Toyota on-line system for any outstanding manufacturer service campaigns.

- Replace engine oil and filter
- Lubricate propeller shaft (4X4 models)
- Tighten propeller shaft bolts (4X4 models)
- Tighten chassis and body nuts and bolts

Inspect the following:


- Drive belts
- Cooling and heater system; check that the radiator and condenser are not blocked with leaves, dirt, or insects, and the hose connections for installation condition and corrosion
- Exhaust pipes/mountings
- Battery
- Water sediment accumulator (diesel models)
- Engine air cleaner filter (all models)
- Fuel tank cap, fuel lines and connections (diesel models)
- Fuel tank cap, fuel lines, connections and vapour control valve (petrol models)
- Brake pedal and parking brake

- Brake pads and discs
- Brake fluid
- Clutch fluid
- Brake pipes and hoses
- Power steering fluid
- Steering wheel and linkage
- Drive shaft boots (4X4 models)
- Suspension ball joints and dust covers
- Front (4X4 models) and rear differential oil
- Front and rear suspensions (4X4 models)
- Tyres and inflation pressures
- Lights, horns, wipers and washers
- Air conditioner, including refrigerant level
- Road test vehicle

140,000 KM OR 84 MONTH SERVICE
(whichever occurs first)

140,000 km or 84 month
(whichever occurs first)

Maintenance Record



TOYOTA GENUINE
PARTS, SERVICE & ACCESSORIES

This service has been completed by an
Authorised Toyota Service Centre using
Toyota Genuine Parts:

Date: *16.8.2014*

Km: *146000*

Toyota Service Centre Verification
Town
Shue

MAINTENANCE FOR NORMAL OPERATING CONDITIONS

IMPORTANT: Check the Toyota on-line system for any outstanding manufacturer service campaigns.

- Replace engine oil and filter
- Lubricate propeller shaft (4X4 models)
- Tighten propeller shaft bolts (4X4 models)

Inspect the following:

- Drive belts
- Cooling and heater system; check that the radiator and condenser are not blocked with leaves, dirt, or insects, and the hose connections for installation condition and corrosion
- Exhaust pipes/mountings
- Battery
- Water sediment accumulator (diesel models)
- Engine air cleaner filter (all models)
- Fuel tank cap, fuel lines and connections (diesel models)
- Fuel tank cap, fuel lines, connections and vapour control valve (petrol models)
- Brake pedal and parking brake

Timing Belt
Fan Belt
Injector Replaced

- Brake pads and discs
- Brake fluid
- Clutch fluid
- Brake pipes and hoses
- Power steering fluid
- Steering wheel and linkage
- Drive shaft boots (4X4 models)
- Suspension ball joints and dust covers
- Front (4X4 models) and rear differential oil
- Front and rear suspensions (4X4 models)
- Tyres and inflation pressures
- Lights, horns, wipers and washers
- Air conditioner, including refrigerant level
- Road test vehicle

170,000 KM OR 102 MONTH SERVICE
(whichever occurs first)

MAINTENANCE FOR NORMAL OPERATING CONDITIONS

IMPORTANT: Check the Toyota on-line system for any outstanding manufacturer service campaigns.

- Replace engine oil and filter
- Lubricate propeller shaft (4X4 models)
- Tighten propeller shaft bolts (4X4 models)

Inspect the following:

- Drive belts
- Battery
- Water sediment accumulator (diesel models)
- Engine air cleaner filter (diesel models)
- Brake pads and discs
- Brake fluid
- Clutch fluid
- Power steering fluid
- Drive shaft boots (4X4 models)
- Tyres and inflation pressures
- Lights, horns, wipers and washers
- Road test vehicle

170,000 km or 102 month
 (whichever occurs first)

Maintenance Record



This service has been completed by an
 Authorised Toyota Service Centre using
 Toyota Genuine Parts:

Date:


Km: 176000

Toyota Service Centre Verification

Tewang
Shire

180,000 KM OR 108 MONTH SERVICE
(whichever occurs first)

180,000 km or 108 month
 (whichever occurs first)
Maintenance Record

 TOYOTA GENUINE <small>PARTS, SERVICE & ACCESSORIES</small>	
This service has been completed by an Authorised Toyota Service Centre using Toyota Genuine Parts:	
Date:	22.7.20
Km:	179000
Toyota Service Centre Verification <i>Towang</i> <i>Shine</i>	

MAINTENANCE FOR NORMAL OPERATING CONDITIONS

IMPORTANT: Check the Toyota on-line system for any outstanding manufacturer service campaigns.

- Replace engine oil and filter
 - Clean air flow meter
 - Replace engine air cleaner filter (diesel models)
 - Lubricate propeller shaft (4X4 models)
 - Tighten propeller shaft bolts (4X4 models)
- 184000*
Change oil + Filter

Inspect the following:

- Drive belts
- Cooling and heater system; check that the radiator and condenser are not blocked with leaves, dirt, or insects, and the hose connections for installation condition and corrosion
- Exhaust pipes/mountings
- Battery
- Water sediment accumulator (diesel models)
- Engine air cleaner filter (petrol models)
- Fuel tank cap, fuel lines and connections (diesel models)
- Fuel tank cap, fuel lines, connections and vapour control valve (petrol models)
- Brake pedal and parking brake
- Brake pads and discs
- Brake fluid
- Clutch fluid
- Brake pipes and hoses
- Power steering fluid
- Steering wheel and linkage
- Drive shaft boots (4X4 models)
- Suspension ball joints and dust covers
- Front (4X4 models) and rear differential oil
- Front and rear suspensions (4X4 models)
- Tyres and inflation pressures
- Lights, horns, wipers and washers
- Air conditioner, including refrigerant level
- Road test vehicle

190,000 KM OR 114 MONTH SERVICE
(whichever occurs first)

MAINTENANCE FOR NORMAL OPERATING CONDITIONS

IMPORTANT: Check the Toyota on-line system for any outstanding manufacturer service campaigns.

- Replace engine oil and filter
- Lubricate propeller shaft (4X4 models)
- Tighten propeller shaft bolts (4X4 models)

Inspect the following:

- Drive belts
- Battery
- Water sediment accumulator (diesel models)
- Engine air cleaner filter (diesel models)
- Brake pads and discs
- Brake fluid
- Clutch fluid
- Power steering fluid
- Drive shaft boots (4X4 models)
- Tyres and inflation pressures
- Lights, horns, wipers and washers
- Road test vehicle

B.9.22
197960
Change oil + Filter + Fuel

190,000 km or 114 month
(whichever occurs first)
Maintenance Record




This service has been completed by an
Authorised Toyota Service Centre using
Toyota Genuine Parts:

Date: 13.1.22
Km: 193000

Toyota Service Centre Verification
Change oil + Filters
oil + Fuel

200,000 km or 120 month (whichever occurs first) Maintenance Record



TOYOTA GENUINE
PARTS, SERVICE & ACCESSORIES

This service has been completed by an
Authorised Toyota Service Centre using
Toyota Genuine Parts:

Date: 17.4.23
Km: 202900

Toyota Service Centre Verification
Towans Shwa

200,000 KM OR 120 MONTH SERVICE (whichever occurs first)

MAINTENANCE FOR NORMAL OPERATING CONDITIONS

IMPORTANT: Check the Toyota online system for any outstanding manufacturer service campaigns.

- Replace engine oil and filter
- Replace spark plugs (petrol models)
- Replace engine air cleaner filter (petrol models)
- Lubricate propeller shaft (4X4 models)
- Tighten propeller shaft bolts (4X4 models)
- Tighten chassis and body nuts and bolts
- Replace brake fluid
- Replace front (4X4) and rear differential oil
- Diesel smoke (diesel models)
- Fuel tank cap, fuel lines and connections (diesel models)
- Fuel tank cap, fuel lines, connections and vapour control valve (petrol models)
- Charcoal canister (petrol models)
- Brake pedal and parking brake
- Brake linings/drums, including parking brake
- Brake pads and discs
- Clutch fluid
- Brake pipes and hoses
- Power steering fluid
- Steering wheel and linkage
- Drive shaft boots (4X4 models)
- Suspension ball joints and dust covers
- Automatic transmission fluid
- Manual transmission oil
- Transfer oil (4X4 models)
- Front and rear suspensions (all models)
- Tyres and inflation pressures
- Lights, horns, wipers and washers
- Air conditioner, including refrigerant level
- Road test vehicle

Inspect the following:

- Check valve clearances (diesel models)
- Brake booster vacuum pump (diesel models)
- Drive belts
- Cooling and heater system; check that the radiator and condenser are not blocked with leaves, dirt, or insects, and the hose connections for installation condition and corrosion
- Engine coolant
- Exhaust pipes/mountings
- Battery
- Water sediment accumulator (diesel models)
- Engine air cleaner filter (diesel models)

19-1-24
209662 oil filter